



# 15" Digital Photo Frame

Instruction manual

---

L15DPF17

---

12 month manufacturer's warranty



# Contents

Safety precautions.....	2
Package contents.....	4
Guide to the device.....	5
Remote control.....	6
Preparations.....	8
Main menu.....	10
Movie play.....	11
Photo play.....	11
Music play.....	12
Ebook.....	13
Setting.....	14
Calendar.....	14
Explorer.....	16
Troubleshooting.....	17
Specifications.....	18

# Safety precautions

Congratulations for purchasing your new digital photo frame. With this Digital Photo Frame, you can easily and quickly view photos directly from your digital camera's memory card. You can even create a slide show with multiple transition effects. The Digital Photo Frame is compatible with the following memory cards and device: SD, MMC and USB device.

## Warning



- High voltage inside. Do not open the casing of the digital photo frame. Refer servicing to qualified personnel only.
- To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
- To avoid permanent loss of data, do not insert or remove memory cards or USB device when the power is on.

## Safety instruction

- The product shall not be exposed to dripping or splashing liquids and no objects filled with liquids, such as vases, shall be placed on the product. Dry location use only.
- No naked flames sources, such as candles, should be placed on or near the product.
- Keep the digital photo frame clean and never store it next to a heat source or in dirty, humid or wet places. Keep it out of direct sunlight.
- Press the buttons gently. Pressing them or the screen too hard can damage the digital photo frame.
- Do not use the product in an extremely dry environment as this can lead to static discharge, which can damage the digital photo frame.
- Do not subject the product to harsh impacts. Do not drop the appliance. These may result in damage to the product and loss of data.
- Do not attempt to repair or disassemble the unit by yourself. Only qualified service personnel should perform repairs.
- The digital photo frame is for indoor use only.
- Only use the DC 12V power adaptor supplied with this product. Do not unplug the adaptor when viewing the pictures.
- Do not block the ventilation holes on the back of the digital photo frame.
- Children should be supervised to ensure that they do not play with the appliance.
- Please unplug the product when you do not intend to use it for a long period of time to prevent overheating and damage to the screen.
- Please insert the plug into the DC IN jack completely on the unit before connecting the AC adaptor to mains supply.
- This product can only play files with compatible format.
- Do not use the product in extreme temperature, the best operating temperature is 5°C-35°C.
- Do not allow metallic objects to touch the DC plug when the player is on.

- Button Battery Warnings

1. CAUTION: Do not ingest battery, Chemical Burn Hazard
2. The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
3. Keep new and used batteries away from children.
4. If the battery compartment does not close securely, stop using the product and keep it away from children.
5. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
6. If you suspect a child has swallowed a button battery, immediately go to a hospital emergency room.
7. Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened.
8. Dispose of used button batteries immediately. Flat batteries can still be dangerous.
9. Tell others about the risk associated with button batteries and how to keep their children safe.
10. Call the Poisons Information Centre on 13 11 26 for additional treatment information.



### **Cleaning and care**

- Always turn off the unit and remove the power adaptor from the mains outlet before cleaning the unit.
- Use a soft dry cloth to clean this product.
- Never spray or pour liquids directly onto the screen or casing.
- Do not use abrasive materials or chemical cleaners such as alcohol, benzene, etc. Do not allow any water or other liquid to enter the appliance.
- Do not drop the unit, which is a complicated electronic device and cannot withstand shock from falls.
- Do not hit or scratch the screen. Handle it with care. The LCD panel of the photo frame is made of glass and therefore is sensitive to excessive force or contact with sharp edges.

# Package contents

Please make sure the following items are included in the package. If an item is damaged or missing, please contact your dealer.



**Main Unit**




**Stand**



**Remote Control**



**AC Adaptor**



**User Manual**


**Items not shown:**

**Statutory notice**

**Warranty card**

# Guide to the device

## Digital Photo Frame view



- 1. Remote sensor
- 2. MENU
- 3. Return
- 4. UP/Previous
- 5. Down/Next
- 6. Right/VOL+
- 7. Left/VOL-
- 8. OK/Enter

- 9. Speaker
- 10. Stand hole
- 11. Mini USB
- 12. SD/MMC card slot
- 13. USB port
- 14. Earphone jack
- 15. Power On/Off
- 16. DC 12V IN

In power on mode, press **MENU** key go directly to main menu. Press **Return** key to return to upper menu. Press **UP/Down/Left/Right** to move the cursor in the menu upward, downward, to the left, or to the right, respectively. Long press **UP/Down** to skip backward/forward when playing video. Press **Left/Right** to turn down/up the volume.

**Note:** Due to production improvements, the appliance may differ slightly from the diagram shown. Diagrams in this instruction manual are for reference only.

# Remote control

## Preparation of the Remote Control

1. Loosen the screw at the rear of the remote control.
2. Push the button towards left.
3. Pull the battery loader out.
4. Insert the battery into the receptacle make sure the polarity matches the marks inside the component.
5. Insert the receptacle into the remote control.
6. Tighten the screw at the rear of the remote control.

## Cell data

Battery type: 1x CR2025, 3 V

Service life: approximately 1 year (for normal use and room temperature)

## Using Of Remote Control

Point the remote control towards the sensor window on the main unit when operating. The remote control works best at a distance less than 3 m and at an angle of up to 30 degree to the front of the unit. No obstacles may stand in the way between remote control and infrared sensor and do not place the remote control in direct sunlight. If the remote control fails to work even when it is operated near the player, replace the battery.


## Notes on batteries








If the remote control is not used for a long period of time, please remove the battery from the compartment.

Do not heat batteries or dispose of them in fires.

Do not dismantle, deform or modify batteries.

## Buttons of the remote control



1. : Power on/off.
2. : Background music for slideshow mode.
3. : Mute the audio of the digital photo frame, press it again to activate the sound.
4. **PHOTO**: Enter the Photo mode directly.
5. : Play or pause the file.
6. : Move the cursor in the menu upward, downward, to the left, or to the right, respectively.
7. **SETUP**: Enter the Setup mode directly.
8. **VOL+**: Turn up the volume.
9. **VOL-**: Turn down the volume.
10. : Fast backward/Fast forward.
11. : Play the previous or next video/audio file.
12. **CALENDAR**: Enter the Calendar mode directly.
13. **ENTER**: Press to confirm selection.
14. **EXIT**: Return to upper menu.
15. **MOVIE**: Enter the Movie mode directly.
16. **MUSIC**: Enter the Music mode directly.



# Preparations

## Getting started:

Step 1: Install the stand at the rear of the digital photo frame.

Step 2: Insert the DC plug of adaptor to the unit and plug the power adaptor into an available AC 100-240V wall outlet.

Step 3: Insert memory devices into the correct slot and turn power to ON position on the side Of the unit.


## Installing the stand

Install the stand to the stand hole; place it on a stable and flat surface so that it stands up.



## Connecting the power supply


1. Place the digital photo frame on a stable and flat surface.
2. Insert the DC plug of the adaptor into the DC 12V IN on the side of the digital photo frame, and then connect power adaptor to an available AC 100V-240V 50/60Hz mains outlet.
3. Switch the **OFF/ON** key on the side of the digital photo frame to power ON/OFF.
4. When the unit is not being used for a long time, switch the **OFF/ON** key to power it off again and unplug the AC adaptor from mains outlet.



## Connecting a USB device


You can view the pictures, listen to music or watch videos from the USB memory device by connecting it to the digital photo frame.

Note: Not all USB storage devices can be read in this digital photo frame.



## Inserting memory cards

To view the pictures, listen to music or watch videos from a compatible memory card, insert it into the respective card slot in the Digital Photo Frame. This Digital Photo Frame is compatible with the following memory cards: • SD • MMC  
Insert a SD or MMC card into the 2-in-1 card slot correctly according to the indication on the unit.




### Notes:

1. This unit can play picture, video and music in USB device or memory card.
2. If your USB device or memory card is loaded with images but do not display, the format of your USB device or memory card might not be compatible with the unit.
3. Do not force the memory card into the slot. If you are not able to insert the memory card easily and completely, you may have inserted it incorrectly.
4. To remove the card, pull out the card slowly. Please DO NOT remove the memory card just after inserting it into the unit or when the unit is processing the files. Wait until the screen is stable.
5. SD Card maximum support is 64GB (FAT32 format), USB maximum support is 8GB(FAT32 format).
6. This unit may not be compatible with all USB devices and memory cards, this is not an indication of a problem with the unit.

### Connecting the computer


Plug in the memory device to the digital photo frame, you can copy pictures, music or video from computer to the memory device by connecting the digital photo frame to a computer. You can also delete files in memory device from computer.



Note: Make sure the USB cable and memory device are well connected before you copy or delete the files.

### Connecting headphones

A stereo earphone jack has been provided on the digital photo frame for private listening. To use this jack, plug in the earphones(not included) with a stereo mini-jack 3.5mm plug to the earphone jack and adjust the volume to a comfortable listening level.




### Notes:

1. When headphones or earphones are connected to the earphone jack, the main speakers will be automatically muted.
2. Be sure that the digital photo frame is set at a low volume level before connecting the headphone.
3. Increase the volume gradually for comfortable listening.
4. Listening at high volume for a long period could cause hearing loss.

### Selecting the memory device

Plug in memory device and then switch **OFF/ON** key on the side of Digital Photo Frame to power on the unit, it will enter Movie play automatically. Press **EXIT** key twice to enter into memory device selecting interface. You will see the options “local disk” and “usb” on the screen, press **▲▼** key to select the desired memory device, then press **ENTER** key to confirm. Press **EXIT** key to return to memory device selecting interface.





**Note:** The Digital Photo Frame may be slow to read some large capacity memory cards and USB devices. Please wait for the device to be recognized.

1. Press ▲▼ key to choose an input source : Memory Card or USB device.
2. Press ◀▶ key to choose Movie/Photo/Music/Ebook/Others mode on main menu.
3. And then press **ENTER** key to confirm your selection.


## Main menu

Turn on the digital Photo Frame and enter into the main menu. If SD/MMC card and USB device containing Movie/Photo/Music are inserted, You will see the options “local disk” and “usb” on the screen, otherwise it will display nulldisk. Press ◀▶ key to choose Movie/Photo/Music/Ebook/Others mode on main menu. press **ENTER** key to confirm your selection.



## Movie play

When a SD/MMC card or USB device containing video is inserted, press ◀▶ key to select Movie mode on the main menu and press **ENTER** key to enter into movie interface, a video playlist will appear.



Press ▲▼ key to select the desired video.

Press **ENTER** key or press **MOVIE** directly on the remote control to start playing the video.

Press ▶|| key to pause or play the video playing.

Press **VOL+ / VOL-** to turn up or turn down the volume.

Press ◀▶ key to skip backward or skip forward the video playing.

Press ◀◀ ▶▶ key to play the previous or next video.

Press **EXIT** key to return to the video playlist, press again to return to main menu.

## Photo play

### Viewing photos

When a SD/MMC card or USB device containing photos is inserted, press ◀▶ key to select Photo mode on the main menu and press **ENTER** to enter into photo interface, a photo playlist will appear.



Press ▲▼ key to select the desired photo.

Press **ENTER** key or press **PHOTO** directly on the remote control to start slideshow.

Press ▶|| key to pause or play the slideshow.


Press **ENTER** key to enter the single picture mode, and press ▲▼ key to skip pictures.

Press 🎧 key to set slideshow with background music if there is an available music file.

Press **EXIT** to return to photo playlist, press again to return to main menu.

## Adjusting photos

When playing a photo, long press **EXIT** key to enter into photo adjusting interface, press ◀▶ key to select Set Bg/Zoom/Rotate/ Slideshow/Scale, press **ENTER** key to confirm selection.



Set Bg: Set the photo as background.

Zoom: Enlarge the photo.

Rotate: Rotate the photo.

Slideshow: Set the style of photo transition while playing slideshow.

Scale: Set the photo display ratio.

## Music Play

When a SD/MMC card or USB device containing music is inserted, press ◀▶ key to select Music mode on the main menu and press **ENTER** to enter into music interface, a music playlist will appear. And the music will play automatically.



Press ▲▼ key to select the desired music or press **MUSIC** directly on the remote control to start playing music.

Press ▶|| key to pause or play the music.

Press **VOL+ / VOL-** to turn up or turn down the volume.

Press ◀▶ to skip backward or forward the music.

Press ◀◀ ▶▶ to play the previous or next music.

Press **EXIT** to return to main menu.

## Ebook

When a SD/MMC card or USB device containing ebook is inserted, press ◀▶ key to select Ebook mode on main menu and press **ENTER** key to enter into ebook interface, a ebook playlist will appear.



Press ▲▼ key to select the desired file and press **ENTER** to start reading.

Press ▲▼ key to display previous or next page.

Press **EXIT** to return to ebook playlist, press again to return to main menu.

When playing a ebook, long press **EXIT** key to enter into e-book setting interface, press ◀▶ key to select music/auto play/color/jump, press ▲▼ key to adjust setting item, press **ENTER** key to confirm. Press **VOL+ / VOL-** to turn up or turn down the volume of background music.



Music: set background music on/off.

Auto play: set auto play speed.

Color: Set the text color.

Jump: select to jump to desired page directly.

# Setting

The Setting interface lets you customise and configure the digital photo frame.

1. Press ◀▶ key to select Other mode on main menu
2. Press ▲▼ key to select Setting mode and press **ENTER** key or press **SETUP** key directly on the remote control to enter into setting interface.
3. Press ▲▼ to select setting items and press **ENTER** to confirm.
4. Press ◀▶ or ▲▼ to adjust the desired option.
5. Press **EXIT** key to return main menu.



Language: Set the system display language.

Slide Speed: Select interval time for slideshow.

Repeat: Select repeat play mode.

Autoplay: Set autoplay mode.

Reset Setting: Select to reset all settings to default.

Breakpoint play: Select to play the same spot on a video file if the video playing is broken off in the middle.

Brightness: Adjust the screen brightness.

Alarm Setup: Set an alarm.

Date: Set the date.

Mode: Select time format to 12-hour or 24-hour.

Time: Set the clock.

Auto Poweron: Set auto poweron time.


Auto Poweroff: Set auto poweroff time.

# Calendar

Press ◀▶ key to select Other mode on main menu. Press ▲▼ key to select Calendar mode and press **ENTER** key or press **CALENDAR** key on the remote control to enter into calendar interface .



Press **ENTER** key to select the calendar display mode.





Long press **EXIT** key, the Date/Mode/Time setting menu will appear. Press ▲▼ key to select Date/Mode/Time, press **ENTER** key to confirm, press ◀▶ or ▲▼ to adjust the desired option.



## Explorer

When a SD/MMC card or USB device containing photo/music/video is inserted, press ◀▶ key to select Other mode on main menu. press ▲▼ key to select Explorer mode, press **ENTER** key to enter into explorer interface, press ▲▼ key to select option, press **ENTER** key to confirm. Long press **EXIT** key to “Yes” or “NO” to delete file, then press ◀▶ key to select option, press **ENTER** key to confirm.



# Troubleshooting

Symptom or problem	Possible cause/solution
No power	The power connector is not completely inserted into the unit.
Screen freezes	The unit may have malfunctioned. Switch it off and wait for a few minutes before turning it on again.
Characters in display are incorrect	Make sure that you have selected the correct language.
Unable to insert memory card or USB device.	Memory card or USB device is not inserted correctly; insert the card in the opposite side.
The unit cannot recognize the memory device inserted.	<ol style="list-style-type: none"> <li>1. Memory card or USB device is not inserted correctly.</li> <li>2. The memory device may be damaged. Please try a new device.</li> <li>3. Make sure that you are using a memory card type, which is supported by the unit.</li> <li>4. Some unpopular memory cards or USB devices are not compatible with the product. Use a memory card or USB device, which matches with the Digital Photo Frame.</li> <li>5. It is slow to read the mass capacity memory device; you should wait for a minute.</li> </ol> <p><b>Note:</b> Not all USB storage devices or Memory cards can be recognized for this digital photo frame.</p>
There is a memory card or USB device inserted in the unit, but the photo frame is not able to read the card or USB device. Connecting the digital photo frame to computer, the computer is not able to visit USB device or SD card via digital photo frame.	<ol style="list-style-type: none"> <li>1. Make sure that you are using a memory card or USB device type, which is supported by the unit.</li> <li>2. Make sure that the memory card or USB device is inserted all the way into the correct slot.</li> <li>3. The memory card or USB device is damaged.</li> <li>4. Make sure the USB cable and memory device are well connected.</li> </ol>

# Specifications

Display	Screen size: 15" color TFT LCD Screen resolution: 1280 x 800 pixels
Power adaptor	Input: AC100-240V, 50/60Hz, 0.65A Max Output: DC 12V 1.5A For use only with Audio/Video or similar equipment.
USB port	USB port 2.0 supports most of the USB device
Support memory cards	SD, MMC
Support picture format	JPEG
Support audio format	MP3
Support video format	AVI, MOV, MKV, MP4 (720P)
Support ebook formart	TXT
Operating temperature	5°C ~ 35°C

**NOTE: As a result of continual improvements, the design and specifications of this product are subject to change without notice and may differ slightly from the unit illustrated on the packaging.**



Distributed by:  
M.E.W. (Australia) Pty Ltd,  
15 Vaughan St, Essendon Fields, Vic 3041  
ACN 152 719 036  
Customer care: Aus-1300 530 800  
customer care@lindenproducts.com.au  
lindenproducts.com.au

While every effort has been made in the preparation of this instruction manual the publishers cannot be held responsible for the accuracy of the information contained herein or any consequence arising from it.

